

# METHOD W SINGLE VALVE

**NOTE: FOR WAX VALVES ONLY  
INCLUDING LV/XL SERIES**



SEE INSTALLATION INSTRUCTIONS  
FOR VALVE SPECIFIC PIPING  
DIAGRAMS AND SET UP  
PROCEDURE.

FOR MULTIPLE TEMPERED LOOPS A  
BALANCING VALVE AND CHECK  
VALVE MUST BE INSTALLED ON  
EACH LOOP AFTER TEMPERED  
FIXTURES.

