

Care & Cleaning Instructions

TM-30, 50, 80, 125, 150, 200, 500, 800, 850, 5125

Cleaning Instructions:

1. Turn off hot and cold water supplies.
2. Loosen LTR set screw and remove cover screws.
3. Remove cover with complete thermostat assembly, submerge in non-corrosive cleaning solution and flush with clean water.
4. Remove port sleeve assembly, submerge in non-corrosive cleaning solution and flush with clean water. (The port sleeve assembly should never be cleaned with abrasive cleaners.)
5. Re-install port sleeve assembly and cover assembly.

NOTE: Before reinserting assembly in valve (with cover gasket) make sure driving ball engages ball socket on thimble.

