
MODEL PNV-300-LF-R DIGITAL TEMPERATURE RECIRCULATION MANIFOLD



APPROXIMATE DIMENSIONS

A = 2' 6" B = 6'
Image not to scale

- Digital Mixing Valve with 3" inlet ball and check valves, 3" Outlet with ball valve and integral RTD Sensor
- 3" inlets, 3" outlet (76.2mm X 76.2mm)
- 0.25 GPM** (.95 L/min) minimum flow capacity
- Controls water temperature to ± 2°F in accordance with ASSE 1017
- Controls water temperature to $\pm 2^{\circ}F$ at the PNV-300-LF during times of low/no system demand
- Maximum operating pressure: 125 PSIG (860KPA)
- Automatic Hot/ Cold Water shutoff upon cold/ hot water inlet supply failure
- User adjustable settings at the controller
- User programmable set point range between 65°F and 180°F
- Displays outlet temperature
- UL Listed 120V plug in power supply with 6' cord
 - · Option for Backup Uninterruptable Power Supply in the event of primary power loss w/ approx. two hours run time
- · Factory assembled and tested

Valve assembly is compliant with Low-Lead requirements of wetted surface area containing less than 0.25% lead by weight. All other fittings and components, the sum total of which comprise the wetted surface of this product contains less than one quarter of one percent of lead by weight.

**NOTE: The valve will maintain temperature with 0.25 GPM flow from the domestic hot water loop when properly installed near the hot water source with a continuously operating recirculation pump.

See Page 3 for Specification Detail, Page 5 for Piping Method Detail & Flow Capacity Chart, Pages 6 and 7 for Options

NEW "ENHANCED FEATURE SET" CONTROL BOX SEE SELECTABLE OPTIONS PAGE 2



Product is non-cancellable and non-returnable from date from order with factory. Signed submittal required with purchase order.



WARNING: This product can expose you to chemicals including lead, which is known to the State of California to cause cancer. For more information, go to www.P65Warnings.Ca.gov

Valves are Pending ASSE 1017 Certified

Valves are Pending CSA Certified

C S US

Valve electronics are UL Certified





1360 Elmwood Avenue, Cranston, RI 02910 USA Phone: 401.461.1200 Fax: 401.941.5310

Email: info@leonardvalve.com

Web Site: http://www.leonardvalve.com



STANDARD CONTROL BOX

PNV-CONTROLLER OPTIONS

Standard Controller 1.0 Version

STANDARD CONTROLLER:


LEONARD

1.0 - See PAGE 1 for info

ENHANCED CONTROLLER OPTIONS:



2.0 – Enhanced Proton Controller with Programable Disinfection Mode



Options:

3T– Three Additional Temperature Sensors for Monitoring of Inlet Hot, Inlet Cold, and Return Temperatures

Depth = 1-3/4"

_ REL - 5 Relay Contacts that Switch during Alarm State • Helpful for Remote Alerts Within Building to Assist

- Maintenance and Service Personnel 5 Unique States:
 - Loss of Power
 - Broken Temperature Probe
 - "Out of Range" Temperature (±10°F)
 - Motor Connectivity and Operation
 - Maintenance (Service Required) @ <90% Full travel



LEONARD

Enhanced Controller 2.0, 2.5, 3.0 Versions


2.5 – Enhanced Proton Controller including all of 2.0 as well as BACnet MS/TP Connection which provides ability to serve up all data to BMS system



Options:

3T – Three Additional Temperature Sensors for Monitoring of Inlet Hot, Inlet Cold, and Return Temperatures


REL – 5 Relay Contacts that Switch during Alarm State (as shown above)



3.0 – Enhanced Proton Controller including all of 2.5 as well as all items below as standard,

WiFi - Wifi enabled

- 3T 3 Additional Temperature Sensors for Monitoring of Inlet Hot, Inlet Cold and Return Temperatures
- REL 5 Relay Contacts that Switch during Alarm State



Leonard Valve Company reserves the right of product, or design modifications without notice or obligation.




1360 Elmwood Avenue, Cranston, RI 02910 USA Phone: 401.461.1200 Fax: 401.941.5310

Email: info@leonardvalve.com

Web Site: http://www.leonardvalve.com

LEONARD MODEL PNV-300-LF-R DIGITAL TEMPERATURE RECIRCULATION MANIFOLD

Image not to scale



- 1. PROTON VALVE AND CONTROLS
- 2. 1-1/2" CHECK VALVE
- 3. 3" FULL PORT BALL VALVE
- 4. 3" CHECK VALVE




1360 Elmwood Avenue, Cranston, RI 02910 USA Phone: 401.461.1200 Fax: 401.941.5310

Email: info@leonardvalve.com
Web Site: http://www.leonardvalve.com

MODEL PNV-300-LF-R 1-1/2" RETURN PIPING METHOD W

Image not to scale

HIGH TEMPERATURE FIXTURES (IF APPLICABLE)



MODEL PNV-300-LF Flow Capacity

MINIMUM		PRESSURE DROP										
FLOW (GPM)	5	10	15	20	25	30	35	40	45	50	PSI	
(I/min)	.3	.7	.97	1.4	1.7	2.1	2.4	2.8	3.1	3.4	BAR	
0.25**	97	135	163	191	213	235	262	288	296	303	GPM	
(.95)	366	510	616	722	805	888	990	1089	1119	1145	I/min	

NOTE: Flowrates will vary depending on existing field conditions. Leonard Valve Company always recommends using CASPAK® sizing software for proper valve sizing and model number applications.



1360 Elmwood Avenue, Cranston, RI 02910 USA Phone: 401.461.1200 Fax: 401.941.5310

Email: info@leonardvalve.com
Web Site: http://www.leonardvalve.com

OPTIONS AND ACCESSORIES

ANY OPTION CHOSEN WILL ALTER PRICING - CONTACT LEONARD VALVE COMPANY FACTORY

BPS Backup Power Supply Unit
R200 2" Recirculation Return Line
CUPC Certified Valve Assembly



_BPS – Backup Power Supply

• Uninterruptable Power Supply with up to 2 hours run time in case of primary power loss

R200-2" Recirculation Return Line

• 2" Copper Piping with with Check Valves

___CUPC – Certified Valve Assembly

- Special wafer check valves included
- For use where cUPC certification is necessary

Engineer's Approval	Job#				
	Arch/Eng.				
	Contractor				

Note: The models shown represent Leonard Products which are believed to be equivalent in type and function to items specified. Leonard Valve Company is not responsible for errors or omissions due to differences in interpretations of information provided.

NOTE: Flow rates will vary depending on existing field conditions. Leonard Valve Company always recommends using CASPAK® sizing software for proper valve sizing and model number applications.

CAUTION! All thermostatic water mixing valves have limitations. They will NOT provide the desired accuracy outside of their flow capacity range. Consult the Flow Capacity Chart and DO NOT OVERSIZE. Minimum flow must be no less than as indicated.

ANY OPTION CHOSEN WILL ALTER PRICING – CONTACT LEONARD VALVE COMPANY FACTORY

Note: Leonard Valve Company reserves the right of product, or design modifications without notice or obligation.



1360 Elmwood Avenue, Cranston, RI 02910 USA Phone: 401.461.1200 Fax: 401.941.5310

Email: info@leonardvalve.com
Web Site: http://www.leonardvalve.com

© 2022 Leonard Valve Company Printed in USA